


Wiring diagram for Fischbach disk rotor motors


0.17-1

Motors: 2x E65, 2x E80


1x 230V 50Hz/60Hz



inlet side with spiral casing



inlet side without spiral casing



TK = Thermal contact (max. 2A)
FM = Fischbach disk rotor motor

Important!

To check the direction of rotation, look at the arrow on the casing. To change the direction of rotation, switch 3 and 4 on a single phase device or switch 1 and 2 on a three phase device.